






Disegno Drawing Чертёж	N° catalogo Part number N° по каталогу	Attacchi Connections Соединитель- ные концы		Pressione statica Static pressure [bar] Статическое давление [бар]	Pressione operativa Working pressure [bar] Рабочее давление [бар]	PS [bar] PS [бар]	TS [°C]		Utilizzo Use использова- ние	Confezione n° pz Package pcs Упаковка, шт
		SAE Flare / развальцовку SAE								
		M	F				min мин	max макс		

CHIAVE MONTAGGIO MECCANISMO VALVOLA / CORE REMOVER (FOR ALL TYPES) / КЛЮЧ ДЛЯ МОНТАЖА МЕХАНИЗМА КЛАПАНА

	8390/A	-	-	-	-	-	-	-	-	10

CAPPUCCI / CAPS WITH GASKET / КОЛПАЧК

	8391/A	-	1/4"	-	-	35	-20	+100	-	100
	8392/A	-	1/4"	-	-	80	-20	+100	-	100
	8392/B (1)	-	1/4"	-	-	80	-20	+100	-	100
	8393/A	-	5/16"	-	-	80	-20	+100	-	100

Note:

- (1) La chiave serve per il montaggio del meccanismo
(1) The key needs to remove the valve core

Примечание.

- (1) Ключ используется при монтаже механизма клапана.